

System configuration

How to enable DOPP on AMD FirePro?

In order to enable the possibility of the GPU hardware hooking on the AMD FirePro graphic cards the DOPP feature has to be enabled.

Use the application **enableDOPP.exe** for this. You can find it by this path:

Start menu -> Vioso Anyblend ->Tools -> AMD DOPP Enable

Reboot after enabling the DOPP.

Please note: Recently we encounter so much issues using AMD D.O.P.P that we cannot treat this as a solution. Until otherwise stated we consider that D.O.P.P. is not available.

Unique solution ID: #1016

Author: Dr. Sergey Kovyryalov

Last update: 2017-07-26 17:35