

Using Calibrations

Why do I still get identical single images on each output after calibrating a mosaic group?

1. The split mode may be set incorrectly. Check your settings in the calibrator options.
2. The version of DirectX on the server might not be up-to-date. Update DirectX to the latest version.

Unique solution ID: #1026

Author: Sven Giersch

Last update: 2016-08-25 12:22