

# Projector calibration

## How to make best calibration conditions?

Before started consider following conditions for successful scanning:

- **Reduce ambient light.** The less ambient light you have the better scanning quality you will get. Turn of the light, close windows etc
- **Adjust your camera properly.** For more details and guidelines check the Vioso Calibrator manual.
- Camera and projectors **must not be moved or shaken** during the scanning process
- **Avoid any interruption** by external influences (person in front of the camera or between projector and surface)
- Check if your **camera and projectors are focused** (But don't use auto-focus!)
- Provide **sufficient projectors overlap.**

Unique solution ID: #1013

Author: Dr. Sergey Kovyryalov

Last update: 2016-08-18 12:53